



SIDEM

INSTALLATION INSTRUCTIONS

! Avoid early wear by following the right placement procedure !

Tie rod ends and ball-joints

- 1 Don't use sharp tools and make sure the dustcover doesn't get pinched during installation. Always check if the dustcover is still intact after mounting.
- 2 Use oil (no grease) to treat the surface of the pin. Apply pressure on the dustcover several times to move it up and down to achieve a smooth movement.
- 3 Always check if the dustcover is in its work position after placement.
- 4 After replacing steering or suspension parts, a wheel alignment must be executed.

