



SIDEM

INSTALLATION INSTRUCTIONS

! Avoid early wear by following the right placement procedure !

Stabiliser links

- 1 Make sure the dustcover doesn't get twisted. The pin must never turn during or after tightening the locknut.



- 2 After installing the stabiliser link, make sure to place it in its correct work position.



- 3 Tighten all bolts and nuts according to the constructors instructions.



- 4 Do not use a pneumatic wrench to tighten the bolts and nuts.

